



# Assembly Instructions for: Big Book Displays - R0044DE

 **Warning:** Choking Hazard  
Assembly hardware contains  
small parts. **Adult assembly required.**



Instructions: Unbox unit and find hardware bag inside of box.

- 1 - Take out shelves from bottom of unit.
- 2 - If shelf clips are not in the shelf support holes place them where you wish them to be. See drawing.
- 3 - Tilt shelf at a slight angle and place one side on the shelf supports and then push down on other side to set shelf into place.
- 4 - Repeat for all other shelves.



If you have any difficulties assembling this product,  
please call Childs Play Customer relations at  
(800) 447-8375 or email us at [mail@childsplay1.com](mailto:mail@childsplay1.com)  
Childs Play 131 Yorktown, Dallas, Tx. 75208  
[www.childsplay1.com](http://www.childsplay1.com)